

Schilling Robotics

Titan 4 Manipulator System

Position-Controlled, 4 Km Submersible



Models:

199-0295

199-0295PAL

199-0296

199-0299

199-0299-1

199-0300

199-0301

199-0307

199-0308-1

199-0308-2

199-0308-3

199-0308-4

199-0308-7

199-0308-81

199-0324

Document No. 011-8239 Rev B.

Copyright © 2012 by Schilling Robotics, LLC. All rights reserved.

Schilling Robotics, the FMC Technologies logo, and their frameworks are trademarks and service trademark applications of FMC Technologies. No part of this document may be reproduced or used in any form without the express written permission of FMC Technologies. Descriptions and specifications are subject to change without notice.

FMC Technologies Schilling Robotics

260 Cousteau Place, Suite 200, Davis, CA 95618 • Ph: (530) 753-6718 • Fax: (530) 753-8092

E-mail: Sales@Schilling.com • Tech.Support@Schilling.com • Customer.Service@Schilling.com

Web Site: <http://www.schilling.com>

TECHNICAL MANUAL REVISION LOG		
Titan 4 Manipulator System, Model Nos. 199-0295, 0295PAL, 0296, 0299, 0299-1, 0300, 0301, 0302, 0307, 0308-1, 2, 3, 4, 7, 8		
TECHNICAL MANUAL: 011-8239		
Description	Date	Rev.
Manual release	March, 2012	A
T4 O7P compatible, 8 pin 20 shell burton connector	June, 2012	B

Table of Contents

Specifications

1 System	9
1.1 Electrical	9
1.2 Telemetry	9
2 Password	9
3 Slave Arm	10
3.1 Specifications	10
3.2 Electrical	10
3.3 Slave Arm Functions	10
3.4 Slave Arm Dimensions & Range of Motion	11
3.5 Sensor	11
4 Master Controller	11
4.1 Specifications	11
4.2 Electrical	11
5 Environmental	11
6 Hydraulics	11
6.1 Fluids	11
6.2 System Requirements	12
7 Compensation	12
8 Custom Features or Modifications	12

Installation

1 User-Supplied Equipment	13
2 Installation Overview	13
3 Mechanical Installation	13
3.1 Slave Arm	13
3.2 Compensator	14
3.3 Junction Box	15
3.4 Master Controller	16
4 Electrical Power & Telemetry Connections	16
4.1 Telemetry Configuration	16
4.2 Long-Line Connections	16

4.3 Deck-Test Connections	18
5 Completing the Installation	19

Operation

1 The Master Controller.	23
1.1 Master Arm	24
1.2 LCD Display Screen	24
1.3 Function Keys	24
1.4 Control Keys	24
1.5 Power Switch	24
1.6 Auxiliary Jaw Switch	25
1.7 Menu Structure	25
1.8 Baud Rate	26
2 Using the Master Controller	26
2.1 Master Arm	26
2.2 Slave Arm Status	27
2.3 Controlling Slave Arm Hydraulics	28
2.4 Controlling Auxiliary Equipment	29
2.5 Menu Security	29
2.6 Incompatibility Alert Screens	29
3 Operation	30
3.1 Pre-Start Checks	30
3.2 Startup	30
3.3 Using the STOW OUT Menu	32
3.4 Using the MAIN Menu	32
3.5 Using the OPERATE Menu	34
3.6 Using OPERATE Menu Options	36
3.7 Using the SHUT DOWN Menu	40
3.8 Shut Down Maintenance	41
3.9 Operating the Optional Wrist Camera	41
4 Setting Performance Options	41
4.1 Using the OPTIONS Menu	41
4.2 Using the SETUP Menu	43
4.3 Enhancing the Slave Arm Position Data Stream	50
5 System Errors & Warnings	50
5.1 Startup with System Warnings	50
5.2 Startup with System Errors	51
5.3 ERR (Error) Message During Operation	52
5.4 Using the SHOW ERRORS Menu	52
5.5 Enabling & Disabling System Error Checking	55
5.6 Diagnosing Master/Slave Problems	56
5.7 Fatal Telemetry Errors	56
6 Avoiding Slave Arm Damage	56

Troubleshooting

1 Preliminary Fault Isolation Procedures	57
---	-----------

1.1 Definitions	57
2 Diagnosing Master/Slave Joint Problems	58
2.1 Uncontrolled Operation	58
2.2 The Stow In/Stow Out Test	58
2.3 Diagnosis with the MASTER TEST Screen	59
2.4 Diagnosis with the Slave Test Screen	60
3 Diagnosing Key and Freeze Button Failures	62
4 Troubleshooting Tables	63
4.1 Screen-Displayed Symptoms	63
4.2 Master Arm Symptoms	65
4.3 Slave Arm Symptoms (Entire Arm).	66
4.4 Slave Arm Symptoms (Individual Joints).	67
4.5 Jaw Symptoms	68
4.6 System Errors	69
4.7 Fatal Telemetry Errors	71
5 Using the Status Indicator LEDs	72
5.1 Slave Controller PCB LEDs.	72
5.2 Master Controller PCB Status LEDs.	72
6 Master Controller Voltage Test Points.	73
7 Factory Assistance.	74

Maintenance & Service

1 Safety First	75
1.1 Worksite Safety	75
1.2 Electrical Safety	76
1.3 Mechanical Safety	76
1.4 Hydraulic Safety.	76
1.5 Deck Testing	77
2 Service Guidelines	77
2.1 Service Assumption	77
2.2 Guidelines	78
2.3 Startup After Maintenance or Service	79
3 Maintenance	80
3.1 Daily Maintenance	80
3.2 Long Term Periodic Maintenance	80
3.3 Cable & Penetrator Maintenance	81
4 Junction Box Service	82
4.1 Fuse Replacement	82
5 Master Controller Service & Configuration	82
5.1 Accessing Internal Components	82
5.2 Adjusting the LCD Screen Viewing Angle.	83
5.3 Changing the System Baud Rate	83
5.4 Master Controller Software Selection	84
5.5 Incompatibility Alert Screens	86

6 Slave Arm Service	89
6.1 Slave Arm Filter Replacement and Cleaning	89
6.2 Emergency Manual Slave Arm Manipulation	91
6.3 Recovery from Water Intrusion	92
6.4 Remove & Install Optional Camera	94
7 System Adjustments & Configuration	97
7.1 Setting Servo Valve Voltage Offsets	97
7.2 Changing the Communication Protocol	98
7.3 Changing the System Baud Rate	100
8 Service & Work Instructions	100
8.1 Index	101
8.2 Instructions for Serviceable Components	101
8.3 Startup Following Maintenance or Service	101

Drawings & Part Lists

1 Organization	143
2 Index	143
2.1 Manipulator System	143
2.2 Deck Test Cables	143
2.3 Slave Arm	144
2.4 Master Controller	145
2.5 Junction Box	145
2.6 Hydraulic Compensator	145
2.7 Spares Kits	145
3 Reference Drawings	145
4 Spares Kits	294
4.1 Standard Spares Kits	294
4.2 Enhanced Spares Kits	303
4.3 Enhanced Spares Sub-Kits	307

Safety & Service Summary

Precautionary Notices

This manual provides precautionary notices which carry important information about safety risks to personnel and damage to equipment while installing, operating, servicing, or maintaining this equipment.

The form and significance of the notices are shown below.



A WARNING alerts you to a risk of injury or loss of life. It may also include instructions to help minimize or eliminate the risk.



A CAUTION alerts you to a risk of equipment damage or loss. It may also include instructions to help minimize or eliminate the risk.

***NOTE:** The absence of WARNING and CAUTION notices does not mean that risk is absent. Always use appropriate safety procedures, equipment, and personal protective equipment (PPE) when operating and servicing this equipment.*

Service Assumption

This manual assumes that service personnel are familiar with the general operating principles, safety guidelines, and service practices associated with the types of equipment represented in this manual.

Security Password

Model No. _____

Serial No. _____

Level 5 Password

This is your level 5 password: 1357



Misuse of the menus accessible with this password can cause malfunctions of the manipulator system, injury to personnel, and/or damage to equipment.

The password for security level 5 is set at the factory and cannot be changed. It provides access to all configurable system menus, including those for setting other security levels and passwords for other operators. See the OPERATION module in your technical manual for complete information on how to use the level 5 password.

Temporary Password, Levels 1-4

The temporary password **0000** is provided for access to security levels 1 through 4 during installation and first startup. This password can be changed to meet your security level requirements.

Security Level 0

Security level 0 is the default level, always available at system startup and requiring no password. While permitting operation, it restricts access to almost all system configuration menus and security features. An operator using a correctly configured manipulator should need no higher privilege level. Levels above 0 require passwords and allow access to specific manipulator system configuration menus.

Specifications

In This Chapter:

- 1 System page 9
- 2 Password..... page 9
- 3 Slave Arm page 10
- 4 Master Controller..... page 11
- 5 Environmental..... page 11
- 7 Compensation page 12
- 8 Custom Features or Modifications page 12

NOTE: The specifications in this chapter apply to the systems listed on the title page, except as noted. The components specific to each system are itemized in the 199-level part lists at the end of the “Drawings & Part Lists” chapter.

1 System

1.1 Electrical

System supply at junction box 90 to 260 VAC, 50-60 Hz, single-phase

1.2 Telemetry

Default protocol RS-232

User-selectable option RS-422/-485 half-duplex 2-wire

NOTE: RS-485 full-duplex telemetry (4-wire) is not supported.

Default baud 19200

User-selectable options 57600 and 115200 baud

NOTE: At 57600 and 115200 baud, additional slave arm joint position data is added to each data packet, however third-party software is needed to utilize it.

2 Password

Access to some master controller menus is password protected. A password information sheet follows the “Table of Contents” section.

- Specifications

3 Slave Arm

3.1 Specifications

Depth rating 4,000 msw (13,124 fsw)
 Maximum reach 1,922 mm (75.7 in.) (from azimuth to gripper T-bar slot)
 Weight in air 100 kg (221 lb)
 Weight in seawater 78 kg (174 lb)

NOTE: Performance specifications use the standard system configuration with Shell Tellus Oil 32 hydraulic fluid, input pressure of 207 bar (3,000 psi) and available flow of 19 lpm (5 gpm).

Lift at full extension, nominal 122 kg (270 lb)
 Maximum lift, nominal 454 kg (1,000 lb)
 Maximum gripper opening (standard gripper), nominal 99 mm (3.9 in.)
 Grip force, nominal 4,092 N (920 lbf)
 Wrist torque, nominal 170 Nm (125 ft-lb)
 Wrist rotation, continuous 360°, 6-35 rpm

3.2 Electrical

Connector

The slave arm connector to system power and telemetry varies with the Titan 4 model. See the 199- part list for this system model.

Input power:

Slave arm 24 VDC

Power consumption:

Slave in-arm controller plus solenoid 6 W start, 12 W run
 Slave arm current draw 1.875 A, at 24 VDC

3.3 Slave Arm Functions

Function	Actuator	Nominal Range
Azimuth	Rotary	240°
Shoulder pitch	Linear	120°
Elbow pitch	Rotary	270°
Wrist pitch	Rotary	180°
Wrist yaw	Rotary	180°
Wrist rotate	Gerotor	360° continuous
Jaw (standard)	Linear	99mm (3.9-in.)

3.4 Slave Arm Dimensions & Range of Motion

See the slave arm drawing in the “Drawings & Part Lists” chapter for:

- Ranges of motion
- Extended dimensions
- Stow dimensions
- Mounting dimensions

3.5 Sensor

Water detection forearm

4 Master Controller

4.1 Specifications

Length 470 mm (18.5 in.)
 Width 177 mm (7.0 in.)
 Height 67 mm (2.6 in.)
 Weight 3.7 kg (8.2 lb)

4.2 Electrical

Input power:

Master controller 90 to 260 VAC, 50-60 Hz, single-phase

Power consumption:

Master controller 6 W start, 3 W run

5 Environmental

Operating temperature -2 to +54° C (+28 to +130° F)
 Storage temperature -15 to +71° C (+5 to +160° F)
 Humidity 0% to 100% condensing

6 Hydraulics

6.1 Fluids

Select a hydraulic fluid based on its maximum temperature during normal operations.

- Lower than 54°C (130°F): Use 22 grade oil.
- Higher than 54°C (130°F): Use 32 grade oil.
- For temperatures above 71°C (160°F), below 0°C (32°F), or when in doubt about which fluid to use, contact your regional technical support representative.
- Do not use water-based fluids.
- If a fluid has been specified for this system to meet special environmental or operational requirements, use it and disregard the parameters listed above.

• Specifications

6.2 System Requirements

Viscosity 10 - 200 cSt
Available flow 5.7 - 19.0 lpm (1.5 - 5.0 gpm)
Pressure 103 bar (1,500 psi) minimum to 207 bar (3,000 psi) maximum

NOTE: Slave arm performance specifications are determined at maximum pressure and flow. Performance diminishes when pressure or flow are reduced.

Hydraulic fluid temperature, maximum 54° C (130° F)
Return pressure, maximum 34.5 bar (500 psi)
Filtration, hydraulic supply 3 microns (10 microns absolute)

NOTE: Use of the recommended filtration will reduce the need to clean or replace the slave arm's internal hydraulic filter (10 microns, 25 microns absolute).

Return relief valve cracking pressure, nominal 500 psi (34.5 bar)
Customer-supplied mating fittings required:

Supply hose fitting -4 JIC female, 1/4-in.

Return hose fitting -6 JIC female, 3/8-in.

7 Compensation

Fluid requirement Non-conductive, non-water based
Compensator fluid capacity 2.2 l (0.58 gal)
Slave arm fluid capacity 9.6 l (2.54 gal)
System total fluid capacity 11.8 l (3.12 gal.)
Fluid pressure (above ambient) 0.48 to 0.69 bar (7 to 10 psi)
Relief valve cracking pressure, nominal 1.4 bar (20 psi)

8 Custom Features or Modifications

Any custom features or modifications present on the supplied Manipulator System are described on the following page(s).